



Airdrive 7.2 has officially launched!

All current devices that were operational on AirDrive 7.1 (old AirDrive platform) will continue to enjoy the free service until the 1st November 2016. There after ALL GSM Commanders will have to be moved to AirDrive 7.2 as our previous version will be discontinued.

ALL new devices added to AirDrive 7.2 (new platform) will now be billed according to theAirDrive subscription you have chosen.

Airdrive Subscriptions

We currently have 3 Airdrive Subscriptions, the **Editor, Historian & Viewer Each Device** receives a Complimentary 1 months worth of FREE Credits when added to the system. **Model Dependency:** * Features are Model Dependant for only GC0641 and GC1281 GSM Commander Models.

Viewer 0 credits per Device/m	ionth
Realtime View	e i
History View	-
History Export	-
Events Realtime View	-
Events History View	-
Events History Export	
Remote Setups	
Remote Control Outputs	-

30

credits per Device/month	
Realtime View	Ø
History View	e
History Export	e
Events Realtime View *	e
Events History View *	đ
Events History Export *	e
Remote Setups	-
Remote Control Outputs	-



100 credits **per** Device/month

Realtime View	e
History View	8
History Export	e
Events Realtime View *	e
Events History View *	e
Events History Export *	e
Remote Setups *	e
Remote Control Outputs *	e

TAKE NOTE : *Features are Model Dependant for only GC0641 & GC1281 GSM Commanders

Credits & Payments explained

Each plan consumes the relevant credits per month depending on which subscription your device has been loaded with.

If you have a Standard GSM Commander loaded on the Editor package then your device will consume 100 credits every month.

Credits are typically purchased once a year for each device. So in the above mentioned example, the Standard GSM Commander on the Editor package, you will purchase the full 12 months worth of credits yearly (1200 credit).

In order to find out the cost per credit please contact your GSM Commander Agent / Installer.

v Features Benetits



Entities Management

Our New Entities Management System enables you to manage your Agents, Customers and Sites in a treelike interface

Devices are now structured to belong to an site, A site belongs to an Customer etc.



User Role Permissions

Our New User Role Permissions allows you to assign user roles to an user, this either giving them an admin role or an standard user role.

Also assigning an User to an Entity, will give them access to only that entity and below.

User Management

Users with the Admin Role can manage users, thus adding, editing a user.

Also assigning of users to an parent entity will only give them access to that entity and below

Events Management

Events/Messages Generated by Devices are populated in the Events View.

A New option to Update an Event with an Description is now availabile, The User and the Date and Time are also stored.

When the event is fully acknowledged you can Finalise the event.



User Interface

An new Updated User Interface have been implemented.

Minimalistic Navigation

To Maximise the available screen area the navigation are now simple hover icons.

Sub Navigation Options Bar

This Options bar are visible on each page with a Entity Scope and Field Filtering Options



Website Tours

A New Feature have been implemented to help users with the new User Interface and Features.

When you visit a page you will be taken though a simple tour of the features of the page.

This will be shown each time until you click "do not show again" for that page.

CONTACT DETAILS

💽 +27 (0) 21 981 7062

sales@gsmcommander.com (\square)

www.gsmcommander.com

Developed and maunfactured in South Africa

GSM COMMANDER